

ONE TIME APPLICATION • LIFE LONG TIRE PROTECTION



**LIQUID**

**BALLAST**

**TIRE SEALANT**



**FOR USE  
WITH ALL  
LIQUID  
BALLASTS**

- ✓ Seals 1/4" Punctures
- ✓ Reclaimable
- ✓ Reusable
- ✓ Environmentally Safe

**Turn Your Liquid Ballast Into A  
Ballast That Seals Punctures!**

**Increase Traction And  
Reduce Tire Slippage**

**Without Worrying About Flat Tires!**

**WORKS WITH:**

**Beet Juice**

**Calcium Chloride**

**Anti-Freeze**

**Water**

LiquiTube® Ballast Sealant installs at a 1 to 10 ratio, meaning that 1 gallon of sealant is installed for every 10 gallons of total ballast.

## Common Tire Application Amounts

Tire	Ballast	Sealant	Tire	Ballast	Sealant	Tire	Ballast	Sealant
11L - 15	15.8 gal	1.6 gal	14.9 - 24	47 gal	4.7 gal	14.9 - 38	67 gal	6.7 gal
11L - 16	16.6 gal	1.7 gal	16.9 - 24	61 gal	6.1 gal	18.4 - 38	110 gal	11 gal
10 - 16.5	12 gal	1.2 gal	17.5 - 25	60 gal	6 gal	18.4 - 46	129 gal	13 gal
12 - 16.5	15 gal	1.5 gal	20.5 - 25	94 gal	9.4 gal	520/85 - 46	153 gal	15.3 gal
14 - 17.5	22 gal	2.2 gal	30.50 - 32	217 gal	2.2 gal	480/80 - 50	125 gal	12.5 gal

To install ballast sealant simply put the valve stem at 3 or 9 o'clock and drain the same amount of ballast out of the tire that you will be adding in LiquiTube® Liquid Ballast Tire Sealant then rotate the valve stem back to 12 o'clock and install the sealant.